

Lab Design Laminates

Le Naturele Wood Collection

VN Series

Continuous Pressed Laminate
(Not a High Pressure Laminate)

Listed below is information on how to handle and fabricate the VN Series:

1. Please handle with care, the product is thin.
2. Please remove from box/crate and let acclimate for 5-7 days before using.
3. After opening pallet or box lay laminate flat and put a heavy substrate on top to keep it from warping. Some warping can be extreme.
4. Never fabricate or store product under 60 degrees or above 90 degrees.
5. Leave your A/C or heater on at all times.
6. Never deliver finished product to a non- temperature controlled environment.
7. This product must always be balanced with a .020 thick phenolic backer. Paint, melamine, paper back or raw back do not count as balanced.
8. Substrate must be MDF or Particle Board (nothing else)
9. Never use this product horizontally or in a high traffic area.
10. Never apply to dry wall without using substrate.
11. Use normal high pressure laminate fabricator techniques when using this product and follow the above instructions.